


# •HOW TO SERVICE YOUR LEWMAR WINCH•



**System** **LEWMAR**

# Dear Owner

Lewmar winches are known world wide for their quality, technical innovation and performance. They have been tested to their limits by our engineers in the laboratory and by racing crews in their search for victory. They have given years of outstanding service to many thousands of yachtsmen to whom the ultimate performance of a yacht or its equipment is perhaps not so important as the pure joy of sailing a fine craft equipped with the best yacht hardware.

This booklet tells you how to give your Lewmar winches the care and attention they need to ensure that whether you sail for results, records or just pleasure, your winches will contribute that extra level of performance that is designed into each Lewmar winch.

Service details of the current range of Lewmar winches are illustrated in this booklet.

The overall servicing principles may be used for earlier versions although the detailed construction of the winches may be different.

Your Lewmar winches have been selected to perform in the best possible manner, with care and attention they will give many years use.

Incidentally, you may like to know that we're the only winch-maker to offer a total sailing system... system Lewmar. System Lewmar includes winches, blocks, shackles, travellers and hatches, portlight, all designed as a family, all working together in harmony. Included in System Lewmar is our range of patented 'WAVEGRIP'® Self Tailing Winches.

If you've ever found yourself short of hands, space, or just plain old muscle power a couple of Lewmar self tailing winches will make all the difference. By freeing you of the necessity to tail the sheet a self tailer enables you to use both hands to wind.

Lewmar's patented Wavegrip concept is simple, safe, and convenient... aren't those the features you're looking for.

All precision-engineered by Lewmar to take you closer to the ultimate sailing experience. For further details, see page 26.

Lewmar wish you good sailing for many years to come.

Lewmar Marine Ltd.

## Our guarantee of quality

Lewmar winches have been developed over many years by extensive testing aboard the world's finest racers, long distance cruising yachts and match racing yachts such as 12 metres. They are manufactured to quality standards in excess of those required by Lloyds and only the finest materials are used.




If installed, used and maintained as described in this booklet, they will give outstanding performance.

Lewmar undertake that any winch which proves defective in materials or workmanship within 1 year of the date of supply will be repaired

or replaced FREE OF CHARGE provided that the winch is returned by the registered owner to the nearest Lewmar office or distributor for examination. Lewmar reserve all rights on determining the nature of the alleged fault and their decision is final.

Contents	Page
When Do Lewmar Winches Need Servicing?	4
What Do I Need - Tools, Spares Kits, Service Manuals	4 & 5
Fitting Your Lewmar Winch	6
Using Self Tailing Winches	7
Self Tailer Adjustment - 16ST to 65ST	8
Servicing Single Speed Winches - 6, 7, 8	9
Servicing Two Speed Winches - 16, 24, 30, 40, 43, 46, 52	10-12
Servicing Three Speed Winches - 48, 55, 65	13-15
Servicing Halliard Winch - No. 1	16
Servicing One Speed Self Tailing Winches - 16ST	17
Servicing Two Speed Self Tailing Winches - 30ST, 40ST, 43ST, 46ST, 48ST, 52ST, 55ST, 56ST, 65ST, 66ST	18-22
Servicing Three Speed/Three Gear 55/3, 65/3, Standard and Self Tailing Winches	23
Servicing Electric Winches	24
Your Lewmar Guarantee and Counterfoil	25
Enquiry Card (including guarantee return) for Information on Other Lewmar Products	26
Lewmar Distributor and Service Addresses	26-27



# WHEN TO SERVICE.

## Frequency of Servicing

Lewmar winches, like any other precision engineered product, must be serviced regularly. Yacht winches are required to carry deceptively high loads. For example the genoa sheet load on a 40 foot cruising yacht could easily be 1000lbs. Regular servicing with attention to correct assembly and condition of parts is vital.

## When?

1. MONTHLY: All Lewmar sheet winches should be lightly oiled and greased as shown.

2. TWO OR THREE TIMES DURING ACTIVE SAILING SEASON: All Lewmar winches should be stripped, cleaned and re-lubricated.

3. AT THE END OF EACH SAILING SEASON AND BEFORE STARTING THE NEW SAILING SEASON: All Lewmar winches should be completely stripped, cleaned, thoroughly checked for damage and lubricated using the full maintenance manual.

## General External Cleaning of Drum

Chromed Winches – Wash drum regularly with fresh water and dry with chamois leather.

OCCASIONALLY use non abrasive liquid chrome cleaner to remove dirt deposits.

Anodised Aluminium Winches – Wash drum regularly with fresh water and dry with chamois leather. DO NOT USE POLISHES OR ABRASIVES.

Stainless Steel Winches – Wash drum regularly with fresh water and dry with chamois leather.

OCCASIONALLY use non abrasive liquid cleaner to remove dirt deposits.

# WHAT YOU NEED.

## WINCH SPARES KIT

Lewmar provide a maintenance kit for each winch in their range. These kits contain parts which owners may damage or mislay. Each kit is complete and parts are not sold separately.

### Typical parts include:–

Pawls, springs, circlips, washers, locking caps, etc.

## Spares Kits

- |      |  |
|------|--|
| 7001 | <b>Basic Winch Servicing Kit</b><br>(4 circlips, pawls, pawl springs)  |
| 7002 | <b>Winch Servicing Kit</b> (4 circlips, 8 pawls, 12 pawl springs, 3 keys, 2 pan head screws – self tailors)  |
| 7003 | <b>Three Speed Winch Servicing Kit</b>   |
| 7009 | <b>Allen key set</b>   |
| 7010 | <b>Grease.</b> Packed in handy 100g plastic tube   |
| 7011 | <b>Grease.</b> Packed in handy 300 gm plastic tub. This waterproof grease contains solid activation which aids the load carrying characteristics of a winch. It is also suitable for trailer wheel bearings, steering gear, hydraulic equipment outboard engines and many other marine applications. |
| 7012 | <b>Assembly Paste.</b> Packed in a handy 300 gm tub.   |
| 7013 | <b>Naval Jelly.</b> Packed in handy 200ml jar. Removes staining of stainless steel surfaces and passivates the material.   |



## WHAT TOOLS DO I NEED?

Any winch can be stripped for servicing in seconds, using a very basic set of tools as described in the table below, and winches introduced from December 1983 onwards need nothing more than a cross head screwdriver and cleaning materials.

### Tools required, for routine servicing

Model	Tools
All models – basic requirement	Small screwdriver or knife blade Clean non-fluffy cloth Cleaning fluid Lubricants
6, 7, 8, 10, 16, 24, 30, 40, 42, 1H	basic requirement only
16ST, 30ST, 34ST	plus soft mallet
40ST, 42ST	plus $\frac{3}{8}$ " A/F Allen Key
44, 48, 44ST, 48ST	plus $\frac{3}{2}$ " or $\frac{5}{16}$ " A/F Allen Key
55, 65, 55ST, 65ST	plus $\frac{3}{8}$ " A/F Allen Key
From Dec. 1983 – 16, 24, 30, 40, 43, 46, 52, 16ST, 30ST, 40ST, 43ST, 46ST, 52ST, 56ST, 66ST	basic plus cross head screwdriver

## SERVICE MANUALS

A full service manual is available from your nearest Lewmar distributor office. Your dealer can supply the correct manual for your particular winch. Full servicing of any winch should not be undertaken without reference to this manual.

For models not mentioned here and earlier models, please contact your Lewmar offices for service details.

### Service Manual Vol VI applies

Winch	Start	End
6	Jan 83	—
7,8	Jan 85	—
16,24,30,40	May 85	—
43,46	Mar 85	—
52	Dec 84	—
48,55,65	Jan 84	—
16ST,40ST	Mar 85	—
30ST,43ST,46ST	Mar 85	—
48ST,55ST,65ST	Jan 84	—
52ST	Dec 84	—
56ST	Mar 87	—
66ST	Dec 88	—
No. 1 Halliard	Jan 78	—


### Service Manual Vol V Specials applies

Winch	Start	End
3 speed, 3 gear		
55/3,65/3	Jan 85	—
3 speed, 3 gear		
55ST,65ST	Jan 85	—
Also coffee grinders and linkage		

### Service Manual Vol VI Specials applies

Winch	Start	End
430,460,520	1987	—
550,650,700	1988	—
900,1100,1200	1989	—
1400	1989	—
Also coffee grinders and linkage		

# FITTING WINCHES




## Fitting your winch

Fitting your winch to achieve the best bolt and output gear support to optimise performance, we suggest you fit your Lewmar winches in the following manner:


1. Remove the drum.
2. Locate the winch base to achieve the best possible bolt support.
3. Mark the location of the bolt holes.
4. Remove the winch.
5. Drill the bolt holes.
6. Apply bedding compound to the underside ensuring that each bolt is bedded but keeping the gear spindles clean and any drain holes clear.  
If the winch is mounted on aluminium an alternative to the bedding compound is a PVC insulating layer.
7. Bolt the winch into place, progressively tightening the bolts.
8. Clean off surplus bedding compound.
9. Refit the drum.
10. Check that the winch is operating correctly.

**N.B.** Please refer to the special instruction provided with every Lewmar Self Tailing and Electric Winch.


## 1 SPEED



## 2 SPEED/3 SPEED



## HALLIARD WINCH




# USING WAVEGRIP

## Self-tailer convenience

If you've ever found yourself short of hands, space or just plain old musclepower, a couple of Lewmar self-tailing winches will make all the difference. By freeing you of the necessity to tail the sheet, a self-tailer enables you to use both hands to wind. Lewmar's patented Wavegrip concept is simple, safe and convenient.

## A closer Look: Self-tailing with Lewmar's Wavegrip®

Ever since its introduction, Lewmar's patented Wavegrip mechanism has set the world standard for self-tailing performance. Other winchmakers had been playing with brawny, rope-chewing spring-loaded jaws; typically, Lewmar engineers used brains instead.



Wavegrip's carefully designed radial 'teeth', set in a wave form, takes ropes of different diameters without adjustment. Each rope finds its own optimum position and is held there, not by cumbersome spring-loaded jaws, but by the load in the line itself. The higher the load, the firmer the grip, yet releasing the rope requires little or no musclepower... just ease it out of the Wavegrip jaws.

Wavegrip handles the rope gently, so there's less wear and tear on your sheets. Another big feature: the low-friction design means you can set the winch up before you tack, and tail the first few metres of slack in by hand... through Wavegrip! Try that on any other self-tailer!



## Self Tailers – How they work


1. The rope must be placed in the jaws correctly. The turn leading from the drum must be passed across the stripper mechanism as shown and placed into the jaws.
2. The winch must be mounted so that the loose sheet falls correctly into a secure stowage position. The position of the stripper arm can be adjusted to give correct feed off of the sheet.
3. There must be a minimum of 3 turns of rope on the barrel.
4. The jaws are designed to accept a range of rope diameters. The winch should only be used with ropes of the sizes recommended.

## Range of rope diameters

Cat. Nos.	Circumference		Diameter	
	(mm)	(ins)	(mm)	(ins)
16ST	26/45	1 1/4	8/14	5/16 / 9/16
30ST	26/45	1 1/4	8/14	5/16 / 9/16
40ST	32/45	1 1/4 / 1 3/4	10/14	3/8 / 9/16
43ST	32/51	1 1/4 / 2	10/16	3/8 / 5/8
46ST	32/51	1 1/4 / 2	10/16	3/8 / 5/8
48ST	32/51	1 1/4 / 2	10/16	3/8 / 5/8
52ST	38/57	1 1/2 / 2 1/4	12/18	1/2 / 3/4
55ST	38/57	1 1/2 / 2 1/4	12/18	1/2 / 3/4
56ST	38/57	1 1/2 / 2 1/4	12/18	1/2 / 3/4
65ST	45/64	1 3/4 / 2 1/2	14/20	9/16 / 1 1/8
66ST	45/64	1 3/4 / 2 1/2	14/20	9/16 / 1 1/8

# ADJUSTING SELF TAILERS

16,30,40,43,46      48,52,55,65




1

Remove 4 screws, in top cap. Remove top cap.



1

Remove 4 socket head screws with a  $\frac{3}{16}$ " A/F Allen Key. Lift off top cap.




Rotate stripper arm to required position, (it can be moved in  $8 \times 45^\circ$  increments, with the winch bolted in place).



2

Remove both collets. Lift off stripper arm and place in required position, ensuring that the stripper arm is placed over the stripper ring in the jaw assembly.



3

Replace top cap and screws.




3

Replace collets, top cap and screws.



# Single Speed 6,7,8




1

Remove circlip with a small screwdriver or knife blade.




Wash centre stem, roller bearings and drum bore with kerosene (paraffin). Dry with a non-fluffy cloth.




2

Lift off the drum, (Remove roller bearings and drum washer on model 8).



Oil pawls in top and bottom of the drum.



Ease out keyway and remove centre spindle.



Grease all parts lightly (including bearings on model 8).

Reassemble winch in reverse sequence. Check for correct operation.


# SERVICING

## 2 Speed 16, 24, 30, 40




1

Remove circlip with a small screwdriver or knife blade.




4

Grease spindle and all other moving parts lightly.



2

Remove top cap, screws, crown and drum. Oil pawls in drum.



5

Remove gear spindle.



3

10 Remove bearings, drum washer and spindle. Clean all parts with kerosene (paraffin). Dry with a non-fluffy cloth, oil spindle pawls.



Remove gears, clean and oil gear pawls and lightly grease other parts.


**Reassemble winch in reverse sequence. Check for correct operation.**

# 2 Speed 43,46




1

Remove circlip with a small screwdriver or knife blade.




Lift out gear spindles and gears, wash and clean all parts.



2

Remove drum, top cap and crown. Refit crown (use anti-seize on crown screws). Remove bearings and drum washer.




Wash, clean, grease gears, bearings and centre spindle.



3


Remove collets from top of centre stem and remove centre spindle.



Oil pawls in both gears.


Reassemble winch in reverse sequence. Check for correct operation.

# 2 Speed 52




1

Remove circlip with a small screwdriver or knife blade. Lift off drum. Remove crown (see p. 11-2).



Wash, clean all parts, grease all 8 bearings and all moving parts.



2

Remove bearings and drum washer. Remove collets from top of centre stem and remove centre spindle.




Oil pawls in both gear sets.



12


Lift out gear spindles and gears taking care that the gear bearings don't fall out.

**Reassemble winch in reverse sequence. Check for correct operation.**



When reassembling take care to place the washers on the bottom of both gear sets (see also p. 21, 6). NOTE: It may help to remove centre stem from base (3 allen screws.)

# 3 Speed 48, 55, 65 Top Action



1

## Servicing Top Cap Assembly

With drum already removed, lift off top cap assembly.



2


Remove large circlip, lift springs and remove plastic closing ring.



Check that closing ring and plunger pin are in good condition.


**Assembly Warning:** When reassembling pawl/ratchet gears, check for correct assembly. Look and check that the pawls seat in the matching ratchet faces.

## Servicing Ratchet Gears



4


Correct location of ratchet gears.




5

Incorrect location of ratchet gears.


## 3 Speed 48, 55, 65 Top Action



Remove circlip with a small screwdriver or knife blade.




Remove collets from top of centre stem and lift off centre stem.



Remove drum and top cap (see p. 13, 1-3), remove cross pin and clutch plate. Remove bearings, wash, clean and grease.




Ensure correct location of plastic end cap studs in pawl sockets.



3

Remove allen screws.




6

Remove gears with bearings, clean and oil paws, and lightly grease all moving parts.

Reassemble winch in reverse sequence. Check for correct operation. See also p. 22, 6.

# 3 Speed 48, 55, 65 Top Action



Remove circlip, drum and top cap assembly. Remove cross pin and clutch plate.



Remove bearings, spacer, drum washer. Release outer screws in base and lift out centre stem assembly.




Remove 3 inner screws in centre stem, release bridge piece (below centre stem). Remove centre spindle, complete with all bearings. Wash, clean and grease.



Remove each gear, wash, clean, and grease all moving parts in winch.  
NOTE: When reassembling, gear order - mid-large-small.




Oil all pawls (including top cap - see also p.13, 1-3), also pawls at bottom of centre spindle




Make sure gear spindle location pins are in the correct position before fitting bridge piece to centre stem. Place main spindle onto smallest gear.


# No 1 Halliard




1 Remove the halliard, releasing the bitter end by unscrewing the  $2 \times \frac{1}{4}$ " UNC grub screws.



Remove brake band and ratchet ring, clean with light abrasive and wash with kerosene (paraffin). Dry with a non-fluffy cloth.



2 Remove circlip with a small screwdriver or knife blade.



3 Remove drum, clean all parts, grease bearings and drive spindle lightly.

**Primary and Secondary Drums** – The main body of the halliard is stored on the primary drum and the turns should be stacked evenly. When the sail is nearly fully hoisted, i.e. within 2 or 3 feet of the black band the final turns should be wound on the secondary drum to avoid crushing the wire.

## Warning

The brake should be tightened firmly before hoisting the sail. When lowering the sail the brake is released as described and the rate of descent controlled with the brake lever. **THE HANDLE MUST NOT BE LEFT IN THE WINCH WHEN THE BRAKE IS RELEASED AS IT WILL REVOLVE. THIS IS DANGEROUS AND CAN CAUSE INJURY. OIL OR GREASE MUST NOT BE APPLIED TO THE BRAKE MECHANISM ON ANY HALLIARD WINCH.**


## NOTE:

When reassembling, ensure pawls engage correctly into ratchet ring.


**Reassemble winch in reverse sequence. Check for correct operation.**




# Single Speed 16ST




1 Remove top cap, collets, stripper arm and drum.




Remove gear spindle, output gear and drive gear. Wash and clean.



2 Remove self tailing jaw assembly, clean all parts, oil pawls in drum and refit.



Start to reassemble. Grease all moving parts lightly and oil pawls in main spindle. Replace bearings and drum.



3 Remove bearings, drum washer and spindle, wash and clean all parts.

**Reassemble winch in reverse sequence. Check for correct operation.**




6 Make sure stripper arm is over stripper ring in jaw assembly (see p. 19, 6). Replace collets by lifting centre spindle. Replace top cap and screws.


# 2 Speed 30ST

1


Remove 4 screws in top cap. Remove top cap.



Lift out gear spindles, remove gears. Wash, clean and grease the gears.




Remove collets, lift out centre spindle.



Oil all pawls.




18 Remove stripper arm, drum. Release self tailing jaw assembly. Clean and refit. Remove bearings and drum washer. Wash, clean and grease bearings. Reassemble winch in reverse sequence




6 Locate gears, insert gear spindles (see pic), make sure stripper arm is over stripper ring in jaw assembly (see p.19, 6). Check for correct operation.

# 2 Speed 40ST, 43ST, 46ST




1  
Remove 4 screws in top cap. Remove top cap.




Lift out gear spindles, remove gears. Wash, clean and grease the gears.




2  
Remove collets, lift out centre spindle.



5  
Oil all pawls.




3  
Remove stripper arm, drum. Release self tailing jaw assembly, clean and refit. Remove bearings and drum washer. Wash, clean and grease bearings.




6  
When reassembling take care that stripper arm is over stripper ring in jaw assembly. Reassemble winch in reverse sequence. Check for correct operation.


# 2 Speed 48ST



1  
Remove 4 screws in top cap ( $\frac{3}{16}$ " A/F Allen Key). Remove top cap.



Lift off centre stem upper. Remove centre spindle, unscrew plastic end cap and oil pawls at end of centre spindle.



Remove stripper arm. Lift off drum assembly, release self tailing jaw assembly, clean and refit. Remove bearings and drum washer. Wash, clean and grease bearings.




Remove gears, oil pawls, grease all moving parts. When reassembling carefully locate centre spindle in gears before replacing centre stem upper.

## Assembly Warning

When reassembling pawl/ratchet gears ensure correct assembly. Look and check that pawls seat in the matching ratchet faces (see also p. 13, 4-5).

**Do not over tighten top cap screws**  
(applies to all models above 48ST).



3  
Remove allen screws in centre stem. Ease out plastic key.


Reassemble winch in reverse sequence. Make sure stripper arm is over stripper ring in jaw assembly (see p. 19, 6). Check for correct operation.

# 2 Speed 52ST, 56ST 66ST




1

Remove 4 screws in top cap ( $\frac{3}{16}$ " A/F Allen Key). Remove top cap




4

Lift out gear spindles and gears taking care that the gear bearings don't fall out.




2

Remove stripper arm. Lift off drum assembly, release self tailing jaw assembly, clean and refit. Remove collets and lift out centre spindle.




5

Oil pawls in both gear sets.



Remove bearings and drum washer. Wash, clean and grease bearings.

**Reassemble winch in reverse sequence. Check for correct operation.**



6


When reassembling take care to place the washers on the bottom of both gear sets and that stripper arm is over stripper ring in jaw assembly (see p. 12-6 and p. 19-6).

# 2 Speed 55ST, 65ST



1

Remove 4 screws in top cap ( $\frac{3}{16}$ " A/F Allen Key). Remove top cap.



Remove 3 inner screws in centre stem, release bridge piece (below centre stem). Remove centre spindle, complete with bearings. Wash, clean and grease.




2

Remove collets, stripper arm. Lift off drum assembly, releasing self tailing jaw assembly, clean and refit.



Proceed and read p. 15, 4-6, p. 19, 6.



3

Remove bearings, spacer, drum washer. Release outer screws in base and lift out centre stem assembly.


## Warning

The winch is self draining, but care should be taken to ensure that the drain holes (on the underside of the base) are not blocked.

**Do not drop drum onto centre stem.**


**Reassemble winch in reverse sequence. Check for correct operation.**

# 3 Speed 55/3, 65/3, 55/3ST, 65/3ST



1

General service as described on p. 15, 1- 6 and p. 22, 1-6. (For adjustment ease plastic cover off bottom push button (in base) with a small screwdriver). \*see 6.




2

Close up showing nut and screw. Plunger is adjusted to effect smooth gear selection. (If in doubt contact nearest Lewmar office).



Adjustment and locking of plunger assembly using box spanner and screwdriver. Tighten nut without moving screw position.



4

Plunger shown in engaged position. Oil and work plunger so that oil migrates and smooth action results.



5

When reassembling complete centre stem to base. The gear change fork (indicated) must line up with the plunger when the plunger is disengaged.

## Warning

The winch is self draining, but care should be taken to ensure that the drain holes (on the underside of the base) are not blocked.

**Do not drop drum onto centre stem.**

**\*If gear change works smoothly leave alone and proceed to 4.**

6

Reassemble winch in reverse sequence. Check for correct operation.

# Electric Winches

For general servicing instructions, follow pages 20, 22 and 23. For specific problems, follow the chart below, or contact your nearest Lewmar office.

## Fault Finding Guide

Symptom	Probable Cause	Remedy
Winch works only in one speed	Motor polarity	Check wiring polarity to motor and reverse if necessary
Winch does not work at all	a. Bad connection	Check all wiring connections especially to battery
	b. Blown fuse or circuit breaker	Check circuit breaker
		Check fuse on encapsulated PC board and replace if blown
		NOTE: Do not alter or interfere with sealed trimmer
		If fuse blows again immediately – contact your Lewmar Agent
	c. Micro-switch in control unit not operating	Check that air switch bellow is operating the micro-switch in control unit
		Adjust for sensitivity if necessary
	d. Insufficient power	Check battery for charge
	e. Worn brushes or brush hung up	Check brushes and commutator on motor and release or replace if necessary

### NOTE:

If the winch requires further servicing, please contact your nearest Lewmar office.





# YOUR LEWMAR GUARANTEE.

## Guarantee Counterfoil

The following particulars will be registered under the terms of our guarantee.

Name \_\_\_\_\_

Address \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Boat Type \_\_\_\_\_

LOA \_\_\_\_\_

Built by \_\_\_\_\_

### Winches

Model \_\_\_\_\_

Model \_\_\_\_\_

Model \_\_\_\_\_

Model \_\_\_\_\_

Model \_\_\_\_\_

Model \_\_\_\_\_

### Winches Supplied (Please tick)

☐ came with boat

☐ fitted by boatyard/dealer

☐ purchased from dealer/chandler

Date \_\_\_\_\_

# YOUR LEWMAR GUARANTEE.

The following particulars will be registered under the terms of our guarantee.

Name \_\_\_\_\_

Address \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Boat Type \_\_\_\_\_

LOA \_\_\_\_\_

Built by \_\_\_\_\_

### Winches

Model \_\_\_\_\_

Model \_\_\_\_\_

Model \_\_\_\_\_

Model \_\_\_\_\_

Model \_\_\_\_\_

Model \_\_\_\_\_

### Winches Supplied (Please tick)

☐ came with boat

☐ fitted by boatyard/dealer

☐ purchased from dealer/chandler

**Please complete reverse also**

Date \_\_\_\_\_



### NOTE

Please return to your nearest Lewmar office – shown overleaf

# FURTHER INFORMATION

I am interested to receive more details of System Lewmar to compliment my Winches. Please send me details and brochures, as shown on the back page.

Hatch / Hardware 1989 Catalogue ☐

Winches 1989 Catalogue ☐

Powerboat Products ☐

Service Manual VI ☐

Service Manual V Specials ☐

Service Manual VI Specials ☐

Navtec Rigging ☐

Navtec Hydraulics ☐

Commander Push Button Sailing ☐

New Products ☐

Newsletter ☐

Holdfast Anchor Windlass ☐

## Lewmar Subsidiary Companies, Regional Distributors and Distributors/ Service Centres in the USA

### LEWMAR

#### Head Office:

**Lewmar Marine Limited**  
Southmoor Estate, Havant  
Hampshire PO9 1J; England  
tel: Havant (0703) 471941/3  
tlx: 86342 LEWMAR G  
fax: (0703) 476043

#### Subsidiaries:

**Lewmar UK Subsidiary**  
Address As Head Office

**Lewmar Sud Europe SARL**

Avenue Marillac  
La Vile En Bois  
17000 La Rochelle, France  
tel: (46) 59 90 46  
tlx: 88238 YACINT G F  
fax: (46) 30 58 34

**Lewmar Mid-Europe B.V.**

Branderweg 19  
8047 PZ Zwolle, Benelux  
Holland  
tel: (38) 216 666  
tx: 42298 LEWMAR N  
fax: (38) 236 643

**Lewmar Sud Europe Cannes**

284 Avenue Michel Jourdain  
06100 Cannes-la-Bocca  
France  
tel: (33) 93 24 86 03  
tx: 42067  
fax: (33) 93 24 15

**Lewmar Marine Inc. (East Coast)**

24 Broad Common Road  
Bristol, Rhode Island 02801, USA  
tel: (401) 254 6200  
tx: (401) 254 6200  
fax: (401) 253 9967

**Lewmar Marine Inc. (West Coast)**

945 Calle Amador, Unit P  
San Clemente  
CA 92672 USA  
tel: (714) 351 6880/583 6882  
tx: 966047 LMKWC  
fax: (714) 361 6802

**Lewmar Marin AB**

Box 6773, S-72106 Sandviken  
Sweden  
tel: (08) 98 04 75  
tx: 1284 LEWMAR S  
fax: (08) 296 189

**Lewmar Marine Limited**

410 Speed Road  
Unit 2  
Oakville, Ontario  
L6L 5M1  
Canada  
tel: (416) 827 8916  
fax: (416) 827 2892

**Full service care, spare parts and assistance are available worldwide. In case of any difficulty please contact your nearest Lewmar office or distributor.**

### Regional Distributors:

#### ARGENTINA

**Klein SA**

PO Box 568  
1000 Buenos Aires  
tx: 18/39 KLEIN  
fax: (54) 1 3612684

**Navitronic**

Maipu 802  
1646 San Fernando  
Buenos Aires  
tx: 26088 NAVI AR  
fax: (54) 7455391

#### AUSTRALIA

**Warwick Hoban & Associates**

11 South Road, Brighton Beach  
Victoria 3186  
tel: (03) 592 7077  
fax: (03) 5928696

#### AUSTRIA

**Horst Welebn**

Brannenfeldstrasse 15  
A 4020 Linz  
tel: (732) 307773  
tx: 22276 WELEBN A

#### BERMUDA

**Inwater Yacht Management**

PO Box HM 600  
Hamilton S  
tel: 809-2228648  
tx: 3246 CWAGY BA

#### BRAZIL

**O. Veleiro Importacao**

**E Exportacao Ltda**  
Rua Teofilo Ottoni 48  
20090 Rio de Janeiro  
tel: (21) 233 3275/3025  
tx: 2.30216 VIEB BR

#### CANARY ISLANDS

**Nordest**

C/Juan Bautista 57  
Santa Cruz De Tenerife  
tel: 922264871  
tx: 92230  
fax: 22.242 428

#### CARIBBEAN

**Hi-Tech Caribbean Ltd**

PO Box 325  
Road Town, Tortola  
British Virgin Islands  
tel: 809-494-3811  
tx: 7969 HDSAIL VB  
fax: (809) 4942334

**Goodwood Marine**

4 Goodwood Crescent  
Goodwood Park, Trinidad  
West Indies  
tel: 63 24612  
tx: 276 FTWIR WC

**Ship Shop Martinique**

6 Rue Joseph Compere  
97200 Fort De France  
tel: (596) 714340  
tx: 912302  
fax: 186355

**C.O. Williams Ltd**

Warrens  
St Michael  
Barbados  
West Indies  
tel: 809-4252250  
tx: 2366 COWWB  
fax: 809 4240374

#### BARBADOS

c/o UK Subsidiary

## CHILE

**Winnco Ltd**  
Apoquindo 6415 OF 96  
Santiago  
tel: 2126494  
fax: 2322644

## CYPRUS

**Mercury Divers Co. Ltd.**  
53 Spyrou Aranzou St.  
PO Box 469, Larnaca  
tel: 051 65492  
tlx 4976 MFRC DIVE CY

## DENMARK

**Münter Marine A/S**  
Sundkrogskaj 12  
DK 2100 Copenhagen  
tel: (01) 184400  
tlx 19699 RAUNTER DK  
fax 01-271700

## FINLAND

**Vestek Oy AB**  
Martintie 3  
SF-02270 ESPOO  
Finland  
tel: 803 6655  
tlx: 121269 VSTEK SF  
fax: 0 803 9102

## GERMANY

**Martin Horst GmbH & Co.**  
Steindamm 52-54  
2820 Bremen 77/FDR  
tel: (0421) 638940  
tlx: 245924 MAROS D  
fax: (0421) 6364291

## GIBRALTAR

**H. Sheppard and Co. Ltd.**  
Waterport, Gibraltar  
tel: (350) 77183  
tlx: 2324 MAKINA GK  
fax: (350) 74754 ATTN HS

## GREECE

**Tecrep Marine SA**  
Akti T. Moutsopoulos  
38 Passalunani, Piraeus  
tel: (1) 4521847  
tlx: 211082 TTP1 GR  
fax: (1) 4184280

## TURKEY

**Kaptan Denizcilik Tic**  
Ahmet Mithat Elendi  
13/1 Kalamis Istanbul  
tel: 337 2000  
fax: (1) 348 2999

## HONG KONG

**Far East Yacht Specialists Limited**  
M2 Floor Baskerville House  
22 Ice House Street  
Hong Kong  
tel: 5 229394/5 226752  
tlx: 65925 KREMA HX  
fax: 5-8432756

## The Boatique

Shop 10 11,  
C/F Aberdeen Marina Building  
8 Shum Wan Road  
Aberdeen  
Hong Kong  
tel: 5 589355  
tlx: 65925 KREMA HX  
fax: 5-8432756

## ICELAND

c/o Lewmar AB Sweden

## ISRAEL

**Briza Yacht & Marine Supply**  
Tel Aviv P.O.B. 39232  
Israel  
tel: 03 202599 284432  
tlx: (03) 265871 G Attn Ref: Aur 137

## ITALY

**Tomasoni Topsail**  
Via E. Ton 85  
16035 Rapallo CE  
tel: 0185-62402  
tlx: 271346 ITS I  
fax: 185 273195

## JAMAICA

c/o UK Subsidiary

## JAPAN

**Nakamura Sengu Kogyo Co. Ltd.**  
No. 105 Aoi Cho 6 Chome  
Naka-ku, Yokohama 231  
tel: (45) 68 10 94  
tlx: 3822853 RLPPO J  
fax: (45) 2617009

## MALTA

**Ripard, Larvan and Ripard Ltd.**  
156 Ta' Xbiex Sea Front  
tel: Ozira 31583  
tlx: 994 YOTS MW

## NEW CALEDONIA

**Marine Corail**  
BP 848, Noumea  
tel: 428222  
tlx: 333 FP  
fax: 435983

## NEW ZEALAND

**Marine Power and Service**  
50 Cook St. City, Auckland 1  
tel: (9) 770335  
tlx: 21877 SEAGEAR  
fax: (9) 378833

## NORWAY

**With Marine A/S**  
3470 Slemmestad Centrum AB  
tel: (02) 2796724  
fax: (02) 2797483

## PERU

**Atlas Zeimex**  
Jose Del Llano  
316 S. Isidro  
100 Lima  
tel: 402036  
tlx: 25202 CP

## PHILIPPINES

**Holiday Boats Inc**  
Bataan Export Processing Zone  
PO Box 100  
BLPZ 1914 BATAAN  
tel: 63147 HBORT  
fax: (632) 8173871 Ext 550/ATTN HBI

## PORTUGAL

**A. Periera Jordao Lda**  
Rua de Jose Falcão  
152-156 Apartado 286 4004 Porto  
tel: 20947/8/9  
tlx: 22308 JORDAO P  
fax: (2) 314169

## SINGAPORE/MALAYSIA

**Swan Marine (Singapore) Pte Ltd**  
10 Collyer Quay  
19 06 Ocean Building  
Singapore 0104  
tel: 3322285  
tlx: 43087  
fax: 3322290

## SOUTH AFRICA

**Central Boating World**  
81 Bree Street  
Cape Town 8001  
tel: (21) 248026  
tlx: 5 26712 SA  
fax: 242564

## SPAIN

**La Industrial Velara Marsal**  
Muntadas 8 Y 10  
Barcelona 74 Espagne  
tel: 4314000  
tlx: 51654 LIVM E  
fax: 432 10 06

## SRI LANKA

**Constellation Yachts**  
1010 Kew Road, Colombo 2  
tel: 35009/35464  
tlx: 1162 RVSL CE

## SWEDEN

**Lewmar Marin AB**  
Sparthagavagen 1591  
43793 Lindome  
tel: 46-3 91 0795  
fax: 46-31910975

## SWITZERLAND

**Bucher and Walt SA**  
Rue de Soleure 8  
CH 2072 St. Blaise  
Neuchâtel  
tel: (038) 336262  
tlx: 952 589  
fax: (038) 336266

## TAIWAN

**Chia Shan Trading Co. Ltd.**  
3 Fl. 126-1 Shih Pai Road  
Sec. 1, Pei Tou District  
Taipei, Taiwan  
R.O.C.  
tel: (02) 834-2871/2  
tlx: 19579 CHAISHAN  
fax: (02) 834 2690

## UK

**Marinac Yacht Fittings Limited**  
24-26 Boswell Square  
Hillingdon Industrial Estate  
Glasgow G62 4 BQ  
tel: 041 883 8723  
fax: 041 883 4638

## X-M Yachting

The Mill, Berwick  
Polegate, East Sussex  
tel: 0323 870092  
tlx: 878144 XMYOTS C  
fax: 0323 870809

## Yacht Tests Limited

22 High Street  
Burnham on Crouch  
Essex CMO AAA  
tel: 0621-782236  
tlx: 995494 YOTEST G  
fax: 0621 784711

## URUGUAY

**Federico Grunwaldt**  
Calle del Comercio 131  
Colonia  
Montevideo  
tel: 504226/966310  
tlx: 22288 Monamic UY  
fax: (2) 962811

## YUGOSLAVIA

**Konim, Titova 38/Vill**  
6100, Ijubljana  
tel: (0) 61 312420/322644  
fax: (0) 61-320350  
tlx: 31251 KONIM YU  
For service contact  
Marko Kavs - Cerkovu 26  
Ljubiana tel: (0) 61-347356

## ZIMBABWE

**Gerber Industrial Marine Centre**  
PO Box 1535, Harare  
tel: 703882  
tlx: 4292 MHGOLD ZW

## Sub Distributors

## AUSTRALIA

Hatches and Portlights only

**Solo Marine Pty. Ltd**  
11 Green Street, Revesby 22.2  
New South Wales  
tel: (02) 7745253  
tlx: AA27045  
fax: (02) 774 5291

Winches and Hardware only -  
NSW and Queensland

## Peter Green Shipchangers

**(Australia) Pty. Ltd**  
12 Palo Avenue, Mona Vale  
Sydney, New South Wales  
tel: (02) 5975411  
tlx: 27533 PCS  
fax: (02) 997 8578

## BENELUX

**Lankhorst Taselaar**  
Binnenhavenweg 31  
821 AA, Lelystad  
P.O. Box 502, 8200 AM Lelystad  
tel: 03200 74611  
tlx: 47177  
fax: 03200 31912

## Proctor Masts Bv

Middenhavensweg 1  
4510 AA, Borskens  
tel: 01172 1397  
fax: 01172 7594

## CANADA

## Service Centres

**The Boathouse**  
Dorval, Quebec  
tel: 514 631 8503

**The Chandlery**  
Ottawa, Ontario  
tel: 513 820 7642

**Dock 16**  
Oakville, Ontario  
tel: 416 844 0116

**Findlay Imports**  
Vancouver, British Columbia  
tel: 604-965-8747

**Harbour Marine Services**  
Port Credit, Ontario  
tel: 416 278 8166

**Genco Sails**  
Toronto, Ontario  
tel: (416) 364 2691

**C. Keeble Sails**  
Belleville, Ontario  
tel: 613 968 9723

**Boulet, Lemelin Inc**  
Quebec City, Quebec  
tel: 418-681-3097

**Ocean Yacht Sales**  
Chester, Nova Scotia  
tel: 902 857 3322

**The Rigging Shoppe**  
Scarborough, Ontario  
tel: 416 752 1711

**Bowline Yachts**  
Winnipeg, Manitoba  
tel: 204-783-9370

**The Store**  
Port Credit, Ontario  
tel: (416) 278 7005

**Storer Sails**

Thornton, Ontario  
tel: (416) 283 9095

**The Yacht Shoppe**

Lunenburg, Nova Scotia  
tel: 902 634 4331

**USA-Manufacturers Sales Representatives**

**R.B. Grove Inc.**  
1105 Calumetway: CT  
Mount Pleasant  
SC 29464  
tel: (803) 881 3353  
fax: (803) 881-1957

**R.B. Grove Inc.**  
281 Southwest 8th Street  
Miami, Florida 33130  
tel: (305) 8545420  
tlx: 230-515615 GROVE MIA

**R.B. Grove Inc.**  
12467 62nd Street North  
Building A, No. 104  
Largo, Florida 34643  
tlx: 293970

**D.A. Stewart & Co**  
301 Annapolis  
Maryland  
tel: (301) 263 4536

**USA Distributors CALIFORNIA**

**Fox Marine Specialists**  
Long Beach  
tel: (213) 426-7111

**Covert Marine, Sacramento**  
tel: (916) 929-7628

**Kettenburg Marine**  
San Diego  
tel: (619) 224 6211

**Hallcraft, Carson**  
tel: (213) 537-1620

**Port Supply, Santa Cruz**  
b-1 (408) 476 1960

**Sailing Supply, San Diego**  
tel: (714) 225 0158

**Svensson Boat Works**  
Aanemaa  
tel: (415) 522 7866

**FLORIDA**

**Glen-Mar Marine Supply Inc.**  
Largo  
tel: (813) 536-1955

**Johnson Sails, St. Petersburg**  
tel: (813) 577-3220

**Lewis Marine Supply**  
Pt. Lauderdale  
tel: (305) 523-4371

**Phillips Marine, Miami**  
tel: (305) 845-8445

**GEORGIA**

**Griffin's Marine Inc., Atlanta**  
tel: (404) 455-0151

**ILLINOIS**

**Barclay Marine Distributors**  
Chicago  
tel: (312) 829 3738

**INDIANA**

**Griffin's Marine Inc., Southbend**  
tel: (219) 234-3707

**MARYLAND**

**Fawcett Boat Supplies**  
Annapolis  
tel: (301) 267 8681

**MAINE**

**Harris Company, Portland**  
tel: (207) 775 5601

**Mansel Marine**  
Rockland  
tel: (207) 596-6464

**MICHIGAN**

**Barclay Marine Distributors**  
Detroit  
tel: (313) 571 1100

**Barclay Marine Distributors**  
Grand Rapids  
tel: (616) 243-6464

**Thomas Hardware**  
Grosse Point Farms  
tel: (313) 886-6094

**MINNESOTA**

**Barclay Marine Distributors**  
St. Paul  
tel: (612) 222-6464

**MISSOURI**

**Covert Marine, Kansas City**  
tel: (816) 421-3100

**NEW JERSEY**

**General Marine Supply Inc.**  
Egg Harbour City  
New Jersey  
tel: (609) 965 2500

**NEW YORK**

**East End Supply Company**  
Greenport  
tel: (516) 477-1900

**Howard Baker Co., Buffalo**  
tel: (716) 854 5967

**Oyster Bay Boat Shop**  
Oyster Bay  
tel: (516) 922-0700

**Roberts Hardware, Utica**  
tel: (315) 797 2350

**TEXAS**

**Blackburn Equipment Company**  
Houston  
tel: (713) 747 8140

**Griffin's Marine Inc., Dallas**  
tel: (214) 247 9080

**WASHINGTON**

**Fisheries Supply Company**  
Seattle  
tel: (206) 632-1462

**Kolstrand/Windward Mark**  
Seattle  
tel: (206) 789 1500

**Marland Enterprises, Seattle**  
tel: (206) 284-3906

**USA Service Centres****US VIRGIN ISLANDS**

**Alan's Rigging**  
Horseport Box NBR 3  
Charlotte Amalie  
USVI 00801 MZ

**CALIFORNIA**

**Bay Riggers, Sausalito**  
tel: (415) 332 5757

**Lewmar Marine Inc. (West Coast)**  
946 Calle Amanecer, Unit P  
San Clemente CA 92672  
tel: (714) 361 6890/6881/6882

**Sea Tek, Marina Del Rey, San Pedro**  
tel: (213) 814-2277

**SOUTH CAROLINA**

**Doyle Sailmakers**  
17 Lockwood Drive  
Charleston, SC  
tel: (803) 722-0823

**CONNECTICUT**

**MacDonald Yacht Rigging**  
Stamford  
tel: (203) 323 5431

**Pilot's Point Marina, Westbrook**  
tel: (203) 399-7906

**Wizard's Marine, South Norwalk**  
tel: (203) 853-0307

**FLORIDA**

**Florida Rigging and Hydraulics**  
Riviera Beach  
tel: (305) 863 7444

**Mack-Shaw Sail Systems Inc.**  
Ft. Lauderdale  
tel: (305) 522-6767

**Riggers Loft**  
Fort Lauderdale  
tel: (305) 525 8410

**Sailing Services, Miami**  
tel: (305) 858-1268

**ILLINOIS**

**Chicago Yachting & Navigation**  
1661 North Elston  
Chicago, IL 60622

**MAINE**

**Handy Boat Service**  
Falmouth Foreside  
tel: (207) 781-5110

**Wayfarer Marine Corp., Camden**  
tel: (207) 236 4378

**MASSACHUSETTS**

**Falmouth Marine, Falmouth**  
tel: (617) 548-4600

**Manchester Marine**  
Manchester, MA  
tel: (617) 526-7911

**MARYLAND**

**Chesapeake Rigging**  
Annapolis  
tel: (301) 268-0956

**MICHIGAN**

**Thomas Hardware Co.**  
Grosse Point Farms  
tel: (313) 886-6094

**RHODE ISLAND**

**Lewmar Marine Inc. (East Coast)**  
Bristol  
tel: (401) 253 6200

**New England Yacht Riggers**  
East Greenwich  
tel: (401) 884-1112

**The Rigging Company**  
Newport R.T. 02840  
tel: (401) 847 8040





**TEXAS**

**Custom Furling & Rigging**  
Seabrook  
tel: 713 334-1851

**South West Nautical**  
Seabrook  
tel: (713) 334 1851

**VERMONT**

**Shelburne Shipyard, Shelburne**  
tel: (802) 985-3326



The range of catalogues available from your dealer, indicate on your guarantee card if you would like to receive your copy direct, or more information on other Lewmar products.

# LEWMAR LIMITED WARRANTY

1. **Warranty:** Lewmar warrants its products, in normal usage, to be free of defects in materials and workmanship for a period of one year from original purchase by the user, subject to the conditions and limitations below. Any part which proves to be defective in normal usage during that one year period will be repaired or replaced by Lewmar.

This Warranty is subject to the following conditions and limitations -

A. Lewmar's liability shall be limited to repair or replacement of goods or parts defective in materials or workmanship.

B. Determination of the suitability of the material for the use contemplated by the buyer is the sole responsibility of the buyer, and Lewmar shall have no responsibility in connection with such suitability.

C. Lewmar shall not be liable for any harm resulting from -

1) failures due to use of products in applications for which they are not intended.

2) failures due to corrosion, wear and tear or improper installation.

D. Lewmar shall not be responsible for shipping charges or installation labour associated with any warranty claims.

E. Service by anyone other than Authorised Lewmar Representatives shall void this warranty unless it accords with Lewmar guidelines and standards of workmanship.

2. **There are no warranties of merchantability, fitness for purpose, or any other kind, express or implied, and none shall be implied by law.** The duration of any such warranties that are nonetheless implied by law for the benefit of a consumer shall be limited to a period of one year from original purchase by the user. Some countries do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

3. **Lewmar shall not be liable for consequential damages to yachts, equipment, or other property, or persons due to any failure of Lewmar equipment.** Some countries do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

4. **This warranty gives you specific legal rights, and you may also have other legal rights which vary from country to country.**

Distributed by:-